



A Simplified Guide to **Airzone Interfaces**




AIRZONE Blueface



Available for:

- ✓ VAF
- ✓ ZBS
- ✓ Easyzone



— Touchscreen icons

- - - - - Informative icons

¹Options available depending on the configuration and/or the HVAC system

For more information, consult the manuals at www.airzonecontrol.com/na/en/support/

AIRZONE


Blueface

FOR AIDOO



Available for:

 Aidoo Pro Line



¹Options available depending on the configuration and/or the HVAC system

²Only available for Aidoo Pro Fan Coil


For more information, consult the manuals at www.airzonecontrol.com/na/en/support/

AIRZONE Think



Available for:

- ✓ VAF
- ✓ ZBS
- ✓ Easyzone



— Touch buttons

- - - Informative icons

¹Options available depending on the configuration and/or the HVAC system

For more information, consult the manuals at www.airzonecontrol.com/na/en/support/

AIRZONE Lite



Available for:

- ✓ VAF
- ✓ ZBS
- ✓ Easyzone

If the status LED is **steady**

The zone is on/activated.

If the status LED is **blinking**

If the LED blinks slowly, it means that the zone is off. It can be turned on again by pressing the LED or from the Airzone Cloud app.


If the LED blinks rapidly in red or purple, it means that there is an error. You can check this from the zone navigation menu on an Airzone Blueface thermostat or using the Airzone Cloud app.

If the status LED is **off**

The thermostat is in energy saving mode, which happens by default. You can configure this in the zone navigation menu from your Airzone Blueface thermostat or using the Airzone Cloud app.

The set-point temperature is the desired temperature.

The default base temperature is 73°F and configured from the *Lite settings* parameter through the zone navigation menu from your Airzone Blueface thermostat or using the Airzone Cloud app.





Airzone Cloud APP





Airzone Cloud

Airzone Cloud
Youtube Playlist >>



 *Please note that your Airzone Cloud App's visualization and control features will depend on the Airzone System Installed and the Level of Access/ Type of Airzone Cloud App Profile.
*Please contact your Airzone Cloud App administration if you need advanced access.



Contact Airzone



Airzone North America Corporation
airzonecontrol.com

For questions navigating our interfaces:
techsupport_na@airzonecontrol.com
+1 866 521 0263



MSTAZX6NSTNA03 | September 2025 Edition

The specifications in this catalog are valid except for typographical errors and may be subject to change without prior notice due to our continuous product improvement efforts. No part of this catalog may be reproduced without the express authorization of Airzone North America Corporation. The content of this catalog is the intellectual property of Airzone North America Corporation.