

A Azul | Blue | Azul | Bleu | Blu
 = Negro | Black | Negro | Noir | Nero
 B Verde | Green | Verde | Vert | Verde
 + Rojo | Red | Vermelho | Rouge | Rosso

AZC25PCB1MOTW


AZAIQSNSOUTB

AZCE6LITEC

AZCE6BLUEZEROC


AZCE6LITEC

AZCE6THINKR[X]



AZAIQBOXDCHM


AZCE8CM1VALC



AZX6AC1VALC

230 V ~


AZC25CB1MOT



AZX6AC1VALR

AZCE8CM1VALR

AZX8AC1MTW1




AZX8GTC[XXX] /
AZX6GTC[XXX] /
AZX6QADAPT[XXX]

DX UNIT

RINT[XXX]BKMRE

CPCC[XXX]MTE

CPRC[XXX]MTE



FOR MORE INFORMATION, CLICK ON THE BLUE REFERENCE

1

2

3

4










5

6

7

8

9



2 x 0.22 + 2 x 0.5 mm²

2 x 0.22 + 2 x 0.5 mm²

3 x 1.5 mm²

2 x 0.22 mm²

2 x 0.22 + 2 x 0.5 mm²



2 x 0.75 mm²

2 x 0.22 mm²

2 x 0.22 + 2 x 0.5 mm²

2 x 0.22 + 2 x 0.5 mm²

N Neutro | Neutral | Neutro | Neutre | Neutro
 L Fase | Phase | Fase | Phase | Fase
 Tierra | Ground | Terra | Terre | Terra



FLEXA 25

[ES] - EQUIPO INVERTER DE CONDUCTOS RECTANGULARES ZONIFICADO CON SUELO RADIANTE HASTA 8 ZONAS

[EN] - ZONED INVERTER UNIT WITH RECTANGULAR DUCT RADIANT HEATING UP TO 8 ZONES

[PT] - UNIDADE DE INVERSOR DE CONDUTA RETANGULAR ZONADA COM AQUECIMENTO POR PISO RADIANTE ATÉ 8 ZONAS

[FR] - UNITÉ GAINABLE RECTANGULAIRE INVERTER AVEC RÉGULATION MULTIZONE ET CONTRÔLE D'ÉLÉMENTS RAYONNANTS (CHAUD) JUSQU'À 8 ZONES

[IT] - UNITÀ A ESPANSIONE DIRETTA CANALIZZATA CON CONDOTTO RETTANGOLARE E IMPIANTO RADIANTE FINO A 8 ZONE

[DE] - RECHTECKIGE INVERTER-KANALEINHEIT MIT ZONEN UND FUßBODENHEIZUNG FÜR BIS ZU 8 ZONEN

	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]
AZC25PCB1MOTW	PACK CENTRAL FLEXA 25 + WEBSERVER [AZX8WS1BWF] + AIRQ IONIZADOR + AIRQ SENSOR + 2 CABLE BUS 15M + MEDIDOR DE CONSUMO	PACK MAIN BOARD FLEXA 25 + WEBSERVER [AZX8WS1BWF] + AIRQ IONIZER + AIRQ SENSOR + 2 BUS CABLE 15M + ELECTRIC METER	PACK CENTRAL FLEXA 25 + WEBSERVER [AZX8WS1BWF] + AIRQ IONIZADOR + AIRQ SENSOR + 2 CABO DE BARRAMENTO 15M + MEDIDOR DE CONSUMO
AZC25PCB1MOTH	PACK CENTRAL FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZADOR + AIRQ SENSOR + 2 CABLE BUS 15M	PACK MAIN BOARD FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZER + AIRQ SENSOR + 2 BUS CABLE 15M	PACK CENTRAL FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZADOR + AIRQ SENSOR + 2 CABO DE BARRAMENTO 15M
AZCE6BLUEZEROC[X]	TERMOSTATO BLUEFACE ZERO [COLOR] AIRZONE	AIRZONE BLUEFACE ZERO [COLOUR] THERMOSTAT	TERMOSTATO BLUEFACE ZERO [COR] AIRZONE
AZCE6THINKR[X]	TERMOSTATO RADIO THINK [COLOR] AIRZONE	AIRZONE THINK [COLOUR] WIRELESS THERMOSTAT	TERMOSTATO RADIO THINK [COR] AIRZONE
AZCE6LITE[C/R][X]	TERMOSTATO [CABLE/RADIO] LITE [COLOR] AIRZONE	AIRZONE LITE [COLOUR] THERMOSTAT [WIRED/WIRELESS]	TERMOSTATO [CABO/RADIO] LITE [COR] AIRZONE
AZX8GTC[XXX] / AZX6GTC[XXX] / AZX6QADAPT[XXX]	PASARELA DE COMUNICACIONES	GATEWAY	GATEWAY COMUNICAÇÕES
RINT[XXXXXX][X]KMRE	AIRZONE TRIPLE SMART GRILLE [SIZE] [COLOUR]	AIRZONE TRIPLE SMART GRILLE [SIZE] [COLOUR]	GRELHA INTELIGENTE TRIPLA AIRZONE [TAMANHO] [COR]
AZCE8CM1VALC	AIRZONE CONTROL MODULE OF RADIANT ELEMENTS	AIRZONE CONTROL MODULE OF RADIANT ELEMENTS	MÓDULO DE CONTROLO DE ELEMENTOS RADIANTES AIRZONE
AZX6AC1VALC	AIRZONE WIRED THERMOSTATIC VALVE ACTUATOR VALC	AIRZONE WIRED THERMOSTATIC VALVE ACTUATOR VALC	CABEÇA TERMOSTÁTICA POR CABO VALC AIRZONE
AZCE8CM1VALR	AIRZONE CONTROL MODULE FOR WIRELESS VALVES VALR	AIRZONE CONTROL MODULE FOR WIRELESS VALVES VALR	MÓDULO DE CONTROLO AIRZONE DE VÁLVULAS SEM FIOS VALR
AZX6AC1VALR	AIRZONE WIRELESS THERMOSTATIC VALVE ACTUATOR VALR	AIRZONE WIRELESS THERMOSTATIC VALVE ACTUATOR VALR	CABEÇA TERMOSTÁTICA SEM FIOS AIRZONE VALR
AZX6ACCTPA	SONDA DE TEMPERATURA CON ABRAZADERA AIRZONE	AIRZONE CLAMP-ON TEMPERATURE PROBE	SONDA DE TEMPERATURA COM BRAÇADEIRA AIRZONE
NOTES	1- Verifique el fabricante de la unidad interior para seleccionar el modelo de la pasarela 2- La distancia máxima para la conexión del cable de la pasarela es de 5 metros	1- Check indoor unit manufacturer to select the correct gateway model 2- Maximum distance for gateway cable connectio is 5 meters	1- Verifique o fabricante da unidade interna para selecionar o modelo de gateway correto 2- A distância máxima para a conexão do cabo do gateway é de 5 metros

	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
AZC25PCB1MOTW	PACK PLATINE FLEXA 25 + WEBSERVER [AZX8WS1BWF] + AIRQ IONISEUR + AIRQ CAPTEUR + 2 CÂBLE BUS 15M + COMPTEUR DE CONSOMMATION	PACK SCHEDA CENTRALE FLEXA 25 + WEBSERVER [AZX8WS1BWF] + AIRQ IONIZZATORE + AIRQ SENSORE + 2 CAVO COLLEGAMENTO 15M + CONTATORE DEL CONSUMATORE	PACK SYSTEMZENTRALE FLEXA 25 + WEBSERVER [AZX8WS1BWF] + AIRQ IONISATOR + AIRQ RAUMLUFTQUALITÄTSFÜHLER + 2 BUS-KABEL 15M + VERBRAUCHSZÄHLER
AZC25PCB1MOTH	PACK PLATINE FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONISEUR + AIRQ CAPTEUR + 2 CÂBLE BUS 15M	PACK SCHEDA CENTRALE FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZZATORE + AIRQ SENSORE + 2 CAVO COLLEGAMENTO 15M	PACK SYSTEMZENTRALE FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONISATOR + AIRQ RAUMLUFTQUALITÄTSFÜHLER + 2 BUS-KABEL 15M
AZCE6BLUEZEROC[X]	THERMOSTAT BLUEFACE ZERO FILAIRE [COULEUR] AIRZONE	TERMOSTATO BLUEFACE ZERO [COLORE] AIRZONE	AIRZONE BLUEFACE ZERO [FARBE] THERMOSTAT
AZCE6THINKR[X]	THERMOSTAT THINK RADIO [COULEUR] AIRZONE	TERMOSTATO THINK RADIO [COLORE] AIRZONE	AIRZONE THINK [FARBE] THERMOSTAT FUNK
AZCE6LITE[C/R][X]	THERMOSTAT [FILAIRE/RADIO] AIRZONE LITE [COULEUR]	TERMOSTATO [CAVO/RADIO] LITE [COLORE] AIRZONE	AIRZONE LITE [FARBE] THERMOSTAT [VERKABELT/FUNK]
AZX8GTC[XXX] / AZX6GTC[XXX] / AZX6QADAPT[XXX]	PASSERELLE DE COMMUNICATION	INTERFACCIA DI COMUNICAZIONE	KOMMUNIKATIONS GATEWAY
RINT[XXXXXX][X]KMRE	GRILLE INTELLIGENTE TRIPLE AIRZONE [TAILLE] [COULEUR]	BOCCHETTA INTELLIGENTE TRIPLA AIRZONE [DIMENSIONE] [COLORE]	AIRZONE TRIPLE SMART GITTER [GRÖSSE] [FARBE]
AZCE8CM1VALC	MODULE DE CONTRÔLE IBPRO6 AIRZONE D'ELEMENTS RAYONNANTS	SCHEDA CONTROLLO RISCALDAMENTO AIRZONE	AIRZONE STEUERMODUL FÜR STRAHLUNGSELEMENTE
AZX6AC1VALC	MOTEUR ÉLECTROTHERMIQUE FILAIRE AIRZONE VALC	TESTINE ELETTROTERMICHE CABLATA AIRZONE VALC	AIRZONE VERKABELTER THERMOSTATISCHER VENTILANTRIEB VALC
AZCE8CM1VALR	MODULE DE CONTRÔLE AIRZONE D'ÉLECTROVANNES RADIO VALR	MODULO DI CONTROLLO AIRZONE PER VALVOLE WIRELESS VALR	AIRZONE STEUERMODUL FÜR FUNKVENTILE VALR
AZX6AC1VALR	TÊTE THERMOSTATIQUE RADIO AIRZONE VALR POR RADIATEURS	TESTINA TERMOSTATICA WIRELESS AIRZONE VALR PER RADIATORI	AIRZONE FUNK-THERMOSTATISCHER VENTILANTRIEB VALR
AZX6ACCTPA	SONDE DE TEMPÉRATURE AVEC COLLIER DE SERRAGE	SONDA DI TEMPERATURA CON FASCETTA AIRZONE	TEMPERATURFÜHLER MIT AIRZONE-KLEMME
NOTES	1- Vérifiez le fabricant de l'unité intérieure pour sélectionner le modèle de passerelle correct 2- La distance maximale pour la connexion du câble de la passerelle est de 5 mètres	1- Verificare il produttore dell'unità interna per selezionare il modello della interfaccia 2- La distanza massima per la connessione del cavo del gateway è di 5 metri	1- Überprüfen Sie den Hersteller des Innengeräts, um das richtige Gateway-Modell auszuwählen 2- Die maximale Entfernung für die Gateway-Kabelverbindung beträgt 5 Meter

ÍNDICE / INDEX / ÍNDICE / INDEX / INDICE / INHALT						
PAG.	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
1	ESQUEMA DETALLADO	DETAIL DIAGRAM	ESQUEMA DETALHADO	SCHÉMA DE DÉTAIL	SCHEMA DI DETTAGLIO	DETAIL-DIAGRAMM
2	ESQUEMA DE INSTALACIÓN	WIRING DIAGRAM	ESQUEMA DE INSTALAÇÃO	SCHÉMA D'INSTALLATION	SCHEMA D'INSTALLAZIONE	INSTALLATIONSVERBINDUNGS SCHEMA
3	HOJA DE REFERENCIA / LEYENDA	REFERENCE SHEET / LEGEND	FOLHA DE REFERÊNCIA / LEGENDA	FEUILLE DE RÉFÉRENCE / LÉGENDE	FOGLIO DI RIFERIMENTO / LEGENDA	REFERENZBLATT / LEGENDE