






HYDRONIC PRODUCTION WITH FLOOR HEATING / COOLING UP TO 8 ZONES



HYDRONIC PRODUCTION WITH UP TO 10 RADIATORS



FLEXA 4.0 DIN

[ES] - EQUIPO HIDRÓNICO CON RADIADORES Y/O SUELO RADIANTE / REFRESCANTE HASTA 8 ZONAS - 10 RADIADORES
[EN] - HYDRONIC PRODUCTION WITH RADIATORS AND/OR FLOOR HEATING COOLING UP TO 8 ZONES - 10 RADIATORS
[PT] - UNIDADE HIDRÔNICA COM RADIADORES E/OU PAVIMENTO RADIANTE / REFRESCANTE ATÉ 8 ZONAS - 10 RADIADORES
[FR] - CONTRÔLE DES RADIATEURS ET/OU PLANCHER CHAUFFANT / RAFRAÎCHISSANT JUSQU'À 8 ZONES - 10 RADIATEURS
[IT] - IMPIANTO AD ACQUA CON RADIATORI E/O PAVIMENTO CALDO / FREDDO FINO 8 ZONE - 10 RADIATORI
[DE] - HYDRONISCHES SYSTEM MIT HEIZKÖRPERN UND/ODER FUßBODENHEIZUNG / -KÜHLUNG FÜR BIS ZU 8 ZONEN - 10 HEIZKÖRPER

	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]
AZCE8CB1DIN	CENTRAL AIRZONE PARA FLEXA 25 EN CARRIL DIN PARA CONTROL RADIANTE FRÍO/CALOR (8Z)	AIRZONE FLEXA 25 MAIN CONTROL BOARD ON DIN RAIL FOR RADIANT HEATING/COOLING CONTROL (8Z)	CENTRAL DE SISTEMA AIRZONE PARA FLEXA 25 EM CALHA DIN PARA CONTROLE DE RADIANTE CALOR/FRIO (8Z)
AZCE6BLUEZEROC[X]	TERMOSTATO AIRZONE BLUEFACE ZERO [COLOR]	AIRZONE BLUEFACE ZERO [COLOUR] THERMOSTAT	TERMOSTATO BLUEFACE ZERO [COR] AIRZONE
AZCE6THINK[R][X]	TERMOSTATO AIRZONE THINK [COLOR] [CABLE/RADIO]	AIRZONE THINK [COLOUR] THERMOSTAT [WIRED/WIRELESS]	TERMOSTATO [RADIO] THINK [COR] AIRZONE
AZCE6LITE[C/R][X]	TERMOSTATO AIRZONE LITE [COLOR] [CABLE/RADIO]	AIRZONE LITE [COLOUR] THERMOSTAT [WIRED/WIRELESS]	TERMOSTATO [CABO/RADIO] LITE [COR] AIRZONE
AZX6WSPHUB	WEBSERVER HUB AIRZONE CLOUD DUAL	WEBSERVER HUB AIRZONE CLOUD DUAL	WEBSERVER HUB AIRZONE CLOUD DUAL
AZCE8CM1VALC	MODULO DE CONTROL AIRZONE DE ELEMENTOS RADIANTES	AIRZONE CONTROL MODULE OF RADIANT ELEMENTS	MÓDULO DE CONTROLO DE ELEMENTOS RADIANTES AIRZONE
AZX6AC1VALC	CABEZAL TERMOSTÁTICO CABLEADO AIRZONE VALC	AIRZONE WIRED THERMOSTATIC VALVE ACTUATOR VALC	CABEÇA TERMOSTÁTICA POR CABO VALC AIRZONE
AZCE8CM1VALR	MODULO DE CONTROL AIRZONE DE CABEZALES INALÁMBRICOS VALR	AIRZONE CONTROL MODULE FOR WIRELESS VALVES VALR	MÓDULO DE CONTROLO AIRZONE DE VÁLVULAS SEM FIOS VALR
AZX6AC1VALR	CABEZAL TERMOSTÁTICO INALÁMBRICO AIRZONE VALR	AIRZONE WIRELESS THERMOSTATIC VALVE ACTUATOR VALR	CABEÇA TERMOSTÁTICA SEM FIOS AIRZONE VALR
AZCE8CM1DRY	MÓDULO DE CONTROL AIRZONE DESHUMECTADOR	AIRZONE DEHUMIDIFIER CONTROL MODULE	MÓDULO DE CONTROLO AIRZONE DESUMIFICADOR

	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
AZCE8CB1DIN	PLATINE AIRZONE FLEXA 25 SUR RAIL DIN POUR LE CONTRÔLE DU CHAUFFAGE/REFROIDISSEMENT RAYONNANT	SCHEDA CENTRALE AIRZONE PER FLEXA 25 SU GUIDA DIN PER IL CONTROLLO RADIANTE CALDO/FREDDO (8Z)	SYSTEMZENTRALE AIRZONE FÜR FLEXA 25 AUF DIN-SCHIENE FÜR DIE WÄRME/KÄLTESTRAHLUNGSKONTROLLE (8Z)
AZCE6BLUEZEROC[X]	THERMOSTAT [COULEUR] AIRZONE BLUEFACE ZERO	TERMOSTATO [COLORE] AIRZONE BLUEFACE ZERO	AIRZONE BLUEFACE ZERO [FARBE] THERMOSTAT
AZCE6THINK[R][X]	THERMOSTAT [COULEUR] AIRZONE THINK [RADIO]	TERMOSTATO [RADIO] THINK [COLOR] AIRZONE	AIRZONE THINK [FARBE] THERMOSTAT [VERKABELT/FUNK]
AZCE6LITE[C/R][X]	THERMOSTAT [COULEUR] AIRZONE LITE [FILAIRE/RADIO]	TERMOSTATO [CAVO/RADIO] LITE [COLORE] AIRZONE	AIRZONE LITE [FARBE] THERMOSTAT [VERKABELT/FUNK]
AZX6WSPHUB	WEBSERVER HUB AIRZONE CLOUD DUAL	WEBSERVER HUB AIRZONE CLOUD DUAL	WEBSERVER HUB AIRZONE CLOUD DUAL
AZCE8CM1VALC	MODULE DE CONTRÔLE IBPRO6 AIRZONE D'ELEMENTS RAYONNANTS	SCHEDA CONTROLLO RISCALDAMENTO AIRZONE	AIRZONE STEUERMODUL FÜR STRAHLUNGSELEMENTE
AZX6AC1VALC	MOTEUR ÉLECTROTHERMIQUE FILAIRE AIRZONE VALC	TESTINE ELETTROTERMICHE CABLATA AIRZONE VALC	AIRZONE VERKABELTER THERMOSTATISCHER VENTILANTRIEB VALC
AZCE8CM1VALR	MODULE DE CONTRÔLE AIRZONE D'ÉLECTROVANNES RADIO VALR	MODULO DI CONTROLLO AIRZONE PER VALVOLE WIRELESS VALR	AIRZONE STEUERMODUL FÜR FUNKVENTILE VALR
AZX6AC1VALR	TÊTE THERMOSTATIQUE RADIO AIRZONE VALR POR RADIATEURS	TESTINA TERMOSTATICA WIRELESS AIRZONE VALR PER RADIATORI	AIRZONE FUNK-THERMOSTATISCHER VENTILANTRIEB VALR
AZCE8CM1DRY	MODULE DE CONTRÔLE AIRZONE DÉSHUMIDIFICATEUR	MODULO DI CONTROLLO AIRZONE DEUMIDIFICATORE	AIRZONE ENTFEUCHTER-STEUERMODUL

ÍNDICE / INDEX / ÍNDICE / INDEX / INDICE / INHALT						
PAG.	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
1	ESQUEMA DETALLADO	DETAIL DIAGRAM	ESQUEMA DETALHADO	SCHÉMA DE DÉTAIL	SCHEMA DI DETTAGLIO	DETAIL-DIAGRAMM
2	ESQUEMA DE INSTALACIÓN	WIRING DIAGRAM	ESQUEMA DE INSTALAÇÃO	SCHÉMA D'INSTALLATION	SCHEMA D'INSTALLAZIONE	INSTALLATIONSVERBINDUNGS SCHEMA
3	HOJA DE REFERENCIA / LEYENDA	REFERENCE SHEET / LEGEND	FOLHA DE REFERÊNCIA / LEGENDA	FEUILLE DE RÉFÉRENCE / LÉGENDE	FOGLIO DI RIFERIMENTO / LEGENDA	REFERENZBLATT / LEGENDE