

AZC25PCB1MOTH

AZAIQSNSOUTB

AZCE6LITEC


AZCE6BLUEZEROC

AZCE6LITEC

AZCE6THINKR[X]


A Azul | Blue | Azul | Bleu | Blu
 = Negro | Black | Negro | Noir | Nero
 B Verde | Green | Verde | Vert | Verde
 + Rojo | Red | Vermelho | Rouge | Rosso

i FOR MORE INFORMATION, CLICK ON THE BLUE REFERENCE




AZAIQBOXDCHM


AZX8AC1MTW1



230 V ~




AZX6WSPHUB




AZX8GTC[XXX] /
 AZX6GTC[XXX] /
 AZX6QADAPT[XXX]


DX UNIT




CPRC[XXX]MTE




CPCC[XXX]MTE



RINT[XXX]BKMRE




1




2 x 0.22 + 2 x 0.5 mm²

2




2 x 0.22 + 2 x 0.5 mm²

3




3 x 1.5 mm²

4




2 x 0.22 mm²

5




2 x 0.22 + 2 x 0.5 mm²

6




2 x 0.75 mm²

7




2 x 0.22 mm²

8



2 x 0.22 + 2 x 0.5 mm²

9




2 x 0.22 + 2 x 0.5 mm²

N Neutro | Neutral | Neutro | Neutre | Neutro
 L Fase | Phase | Fase | Phase | Fase
 Tierra | Ground | Terra | Terre | Terra

FLEXA 25

ZONED VRV UNIT WITH RECTANGULAR DUCT UP TO 8 ZONES PER SYSTEM



FLEXA 25

[ES] - EQUIPO VRF DE CONDUCTOS RECTANGULARES ZONIFICADOS HASTA 8 ZONAS POR SISTEMA

[EN] - ZONED VRF UNITS WITH RECTANGULAR DUCT UP TO 8 ZONES PER SYSTEM

[PT] - UNIDADES VRF DE CONDUTAS RECTANGULARES ZONADAS ATÉ 8 ZONAS POR SISTEMA

[FR] - UNITÉ DRV GAINABLE RECTANGULAIRE AVEC RÉGULATION MULTIZONE JUSQU'À 8 ZONES PAR SYSTÈME

[IT] - INSTALLAZIONE A VRF CON UNITÁ CANALIZZATE CON CONDOTTO RETTANGOLARE FINO A 8 ZONE PER SISTEMA

[DE] - ZONIERTE VRF-GERÄTE MIT RECHTECKIGEN KANÄLEN FÜR BIS ZU 8 ZONEN PRO SYSTEM

	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]
AZC25PCB1MOTH	PACK CENTRAL FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZADOR + AIRQ SENSOR + 2 CABLE BUS 15M + MEDIDOR DE CONSUMO	PACK MAIN BOARD FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZER + AIRQ SENSOR + 2 BUS CABLE 15M + ELECTRIC METER	PACK CENTRAL FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZADOR + AIRQ SENSOR + 2 CABO DE BARRAMENTO 15M + MEDIDOR DE CONSUMO
AZCE6BLUEZEROC[X]	TERMOSTATO AIRZONE BLUEFACE ZERO [COLOR]	AIRZONE BLUEFACE ZERO [COLOUR] THERMOSTAT	TERMOSTATO BLUEFACE ZERO [COR] AIRZONE
AZCE6THINKR[X]	TERMOSTATO AIRZONE THINK RADIO [COLOR]	AIRZONE THINK [COLOUR] THERMOSTAT WIRELESS	TERMOSTATO RADIO THINK [COR] AIRZONE
AZCE6LITE[C/R][X]	TERMOSTATO AIRZONE LITE [CABLE/RADIO] [COLOR]	AIRZONE LITE [COLOUR] THERMOSTAT [WIRED/WIRELESS]	TERMOSTATO [CABO/RADIO] LITE [COR] AIRZONE
AZX8GTC[XXX] / AZX6GTC[XXX] / AZX6QADAPT[XXX]	PASARELA CONTROLADOR AIRZONE [MARCA]	AIRZONE [MANUFACTURER] CONTROLLER GATEWAY	GATEWAY CONTROLADOR AIRZONE [MARCA]
RINT[XXXXXX][X]KMRE	AIRZONE TRIPLE SMART GRILLE [SIZE] [COLOUR]	AIRZONE TRIPLE SMART GRILLE [SIZE] [COLOUR]	GRELHA INTELIGENTE TRIPLA AIRZONE [TAMANHO] [COR]
NOTES	1- Verifique el fabricante de la unidad interior para seleccionar el modelo de la pasarela 2- La distancia máxima para la conexión del cable de la pasarela es de 5 metros	1- Check indoor unit manufacturer to select the correct gateway model 2- Maximum distance for gateway cable connectio is 5 meters	1- Verifique o fabricante da unidade interna para selecionar o modelo de gateway correto 2- A distância máxima para a conexão do cabo do gateway é de 5 metros

	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
AZC25PCB1MOTH	PACK PLATINE FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONISEUR + AIRQ CAPTEUR + 2 CÂBLE BUS 15M + COMPTEUR DE CONSOMMATION	PACK SCHEDA CENTRALE FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONIZZATORE + AIRQ SENSORE + 2 CAVO COLLEGAMENTO 15M + CONTATORE DEL CONSUMATORE	PACK SYSTEMZENTRALE FLEXA 25 + WEBSERVER [AZX6WSPHUB] + AIRQ IONISATOR + AIRQ RAUMLUFTQUALITÄTSFÜHLER + 2 BUS-KABEL 15M + VERBRAUCHSZÄHLER
AZCE6BLUEZEROC[X]	THERMOSTAT [COULEUR] AIRZONE BLUEFACE ZERO	TERMOSTATO [COLORE] AIRZONE BLUEFACE ZERO	AIRZONE BLUEFACE ZERO [FARBE] THERMOSTAT
AZCE6THINKR[X]	THERMOSTAT [COULEUR] AIRZONE THINK RADIO	TERMOSTATO RADIO THINK [COLOR] AIRZONE	AIRZONE THINK [FARBE] THERMOSTAT FUNK
AZCE6LITE[C/R][X]	THERMOSTAT [COULEUR] AIRZONE LITE [FILAIRE/RADIO]	TERMOSTATO [CAVO/RADIO] LITE [COLORE] AIRZONE	AIRZONE LITE [FARBE] THERMOSTAT [VERKABELT/FUNK]
AZX8GTC[XXX] / AZX6GTC[XXX] / AZX6QADAPT[XXX]	PASSERELLE CONTROLEUR AIRZONE [MARQUE]	INTERFACCIA DI CONTROLLO AIRZONE [MARCHIO]	AIRZONE CONTROLLER GATEWAY [MARKE]
RINT[XXXXXX][X]KMRE	GRILLE INTELLIGENTE TRIPLE AIRZONE [TAILLE] [COULEUR]	BOCCHETTA INTELLIGENTE TRIPLA AIRZONE [DIMENSIONE] [COLORE]	AIRZONE TRIPLE SMART GITTER [GRÖSSE] [FARBE]
NOTES	1- Vérifiez le fabricant de l'unité intérieure pour sélectionner le modèle de passerelle correct 2- La distance maximale pour la connexion du câble de la passerelle est de 5 mètres	1- Verificare il produttore dell'unità interna per selezionare il modello della interfaccia 2- La distanza massima per la connessione del cavo del gateway è di 5 metri	1- Überprüfen Sie den Hersteller des Innengeräts, um das richtige Gateway-Modell auszuwählen 2- Die maximale Entfernung für die Gateway-Kabelverbindung beträgt 5 Meter

ÍNDICE / INDEX / ÍNDICE / INDEX / INDICE / INHALT						
PAG.	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
1	ESQUEMA DETALLADO	DETAIL DIAGRAM	ESQUEMA DETALHADO	SCHÉMA DE DÉTAIL	SCHEMA DI DETTAGLIO	DETAIL-DIAGRAMM
2	ESQUEMA DE INSTALACIÓN	WIRING DIAGRAM	ESQUEMA DE INSTALAÇÃO	SCHÉMA D'INSTALLATION	SCHEMA D'INSTALLAZIONE	INSTALLATIONSVERBINDUNGS SCHEMA
3	HOJA DE REFERENCIA / LEYENDA	REFERENCE SHEET / LEGEND	FOLHA DE REFERÊNCIA / LEGENDA	FEUILLE DE RÉFÉRENCE / LÉGENDE	FOGLIO DI RIFERIMENTO / LEGENDA	REFERENZBLATT / LEGENDE