




EASYZONE 25

AZX8AC1MTW1




AZX6GTC[XXX]/AZX6QADAPT3[XXX]/AZX8GTC[XXX]


AZX6WSPHUB




Termostato / Thermostat




AZCE6THINKR[X]



AZCE6LITEC[X]




AZCE6BLUEZEROC[X]



AZCE6LITEC[X]


A Azul | Blue | Azul | Bleu | Blu
 - Negro | Black | Negro | Noir | Nero
 B Verde | Green | Verde | Vert | Verde
 + Rojo | Red | Vermelho | Rouge | Rosso

1




2 x 0.22 + 2 x 0.5 mm²

2




2 x 0.22 + 2 x 0.5 mm²

3




3 x 1.5 mm²

4




2 x 0.22 mm²

5




2 x 0.22 + 2 x 0.5 mm²

6




2 x 0.22 mm²

7




2 x 0.22 + 2 x 0.5 mm²

N Neutro | Neutral | Neutro | Neutre | Neutro
 L Fase | Phase | Fase | Phase | Fase
 Tierra | Ground | Terra | Terre | Terra



AZAIQNSOUTB

ZONED VRV DUCTED SYSTEM WITH MOTORIZED PLENUM FOR UP TO 8 ZONES



EASYZONE 25

[ES] - EQUIPO VRF DE CONDUCTOS ZONIFICADO CON PLENUM MOTORIZADO HASTA 8 ZONAS

[EN] - ZONED VRV DUCTED SYSTEM WITH MOTORIZED PLENUM FOR UP TO 8 ZONES

[PT] - SISTEMA VRF DUTADO ZONIFICADO COM PLENUM MOTORIZADO PARA ATÉ 8 ZONAS

[FR] - SYSTÈME DRV GAINABLE ZONÉ AVEC PLÉNUM MOTORISÉ JUSQU'À 8 ZONES

[IT] - SISTEMA VRF CANALIZZATO ZONIFICATO CON PLENUM MOTORIZZATO FINO A 8 ZONE

[DE] - VRF-KANALGERÄT MIT ZONEN UND MOTORISIERTEM ANSCHLUSSKASTEN FÜR BIS ZU 8 ZONEN

	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]
AZ[C/H]25[XXX][XX][XX] [Range][Size][Number of dumper]	CENTRAL DE SISTEMA AIRZONE EASYZONE - 8 ZONAS	AIRZONE EASYZONE MAIN CONTROL BOARD - 8 ZONES	CENTRAL DO SISTEMA AIRZONE EASYZONE - 8 ZONAS
	AIRQ SENSOR DE CALIDAD DE AIRE INTERIOR CAI [AZX6AIQSNSB]	AIRQ INDOOR AIR QUALITY SENSOR [AZX6AIQSNSB]	SENSOR DE QUALIDADE DO AR INTERNO AIRQ [AZX6AIQSNSOUTB]
	COMPUERTA MOTORIZADA CON IONIZADOR [MEDIDAS] AIRZONE	AIRZONE MOTORIZED DUCT DUMPER [SIZE]	REGISTO MOTORIZADO COM IONIZADOR [MEDIDAS] AIRZONE
	WEBSERVER BÁSICO AIRZONE CLOUD WI-FI [AZX8WS1BWF] O WEBSERVER HUB AIRZONE CLOUD DUAL [AZX6WSPHUB]	BASIC WEBSERVER AIRZONE CLOUD WI-FI [AZX8WS1BWF] O WEBSERVER HUB AIRZONE CLOUD DUAL [AZX6WSPHUB]	WEBSERVER BÁSICO AIRZONE CLOUD WI-FI [AZX8WS1BWF] O WEBSERVER HUB AIRZONE CLOUD DUAL [AZX6WSPHUB]
	PASARELA DE COMUNICACIONES AIRZONE [FABRICANTE]	AIRZONE [MANUFACTURER] COMMUNICATION GATEWAY	GATEWAY DE COMUNICAÇÕES AIRZONE [MARCA]
	MEDIDOR DE CONSUMO ELÉCTRICO MONOFÁSICO WI-FI	SINGLE-PHASE WI-FI ELECTRICITY CONSUMPTION METER	MEDIDOR DE CONSUMO ELÉCTRICO MONOFÁSICO WI-FI
AZCE6BLUEZEROC[X]	TERMOSTATO BLUEFACE ZERO [COLOR] AIRZONE	AIRZONE BLUEFACE ZERO [COLOUR] THERMOSTAT	TERMOSTATO BLUEFACE ZERO [COR] AIRZONE
AZCE6THINKR[X]	TERMOSTATO RADIO THINK [COLOR] AIRZONE	AIRZONE THINK [COLOUR] WIRELESS THERMOSTAT	TERMOSTATO RADIO THINK [COR] AIRZONE
AZCE6LITE[C/R][X]	TERMOSTATO [CABLE/RADIO] LITE [COLOR] AIRZONE	AIRZONE LITE [COLOUR] THERMOSTAT [WIRED/WIRELESS]	TERMOSTATO [CABO/RADIO] LITE [COR] AIRZONE

	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
AZ[C/H]25[XXX][XX][XX] [Range][Size][Number of dumper]	PLATINE CENTRALE AIRZONE EASYZONE 25 - 8 ZONES	SCHEDA CENTRALE EASYZONE - 8 ZONE	AIRZONE EASYZONE-ZENTRALE – 8 ZONEN
	CAPTEUR DE QUALITÉ DE L'AIR INTÉRIEUR AIRQ [AZX6AIQSNSOUTB]	SENSORE DI QUALITÀ DELL'ARIA AIRQ [AZX6AIQSNSOUTB]	AIRQ RAUMLUFTQUALITÄTSFÜHLER [AZX6AIQSNSOUTB]
	REGISTRE MOTORISÉ CIRCULAIRE AVEC IONISEUR [Ø] AIRZONE	SERRANDA MOTORIZZATA CON IONIZZATORE [TAGLIA] AIRZONE	KANALMONTIERTE MOTORISCHE RUNDKLAPPE MIT IONISATOR [ABMESSUNGEN] AIRZONE
	WEBSERVER DE BASE AIRZONE CLOUD WI-FI [AZX8WS1BWF] OU WEBSERVER HUB AIRZONE CLOUD DUAL[AZX6WSPHUB]	WEBSERVER DI BASE AIRZONE CLOUD WI-FI [AZX8WS1BWF] O WEBSERVER HUB AIRZONE CLOUD DUAL [AZX6WSPHUB]	WEBSERVER AIRZONE CLOUD WI-FI DUAL [AZX8WS1BWF] O WEBSERVER HUB AIRZONE CLOUD DUAL [AZX6WSPHUB]
	PASSERELLE DE COMMUNICATION AIRZONE [MARQUE]	INTERFACCIA DI COMUNICAZIONE AIRZONE [MARCHIO]	GATEWAY-CONTROLLER AIRZONE [HERSTELLER]
	COMPTEUR DE CONSOMMATION ÉLECTRIQUE MONOPHASÉ WI-FI	MISURATORE DI CONSUMO ELETTRICO MONOFASE WI-FI	ERSATH-EINPHASEN-WI-FI ENERGIEVERBRAUCHSMESSER
AZCE6BLUEZEROC[X]	THERMOSTAT BLUEFACE ZERO FILAIRE [COULEUR] AIRZONE	TERMOSTATO BLUEFACE ZERO [COLORE] AIRZONE	AIRZONE BLUEFACE ZERO [FARBE] THERMOSTAT
AZCE6THINKR[X]	THERMOSTAT THINK RADIO [COULEUR] AIRZONE	TERMOSTATO THINK RADIO [COLORE] AIRZONE	AIRZONE THINK [FARBE] THERMOSTAT FUNK
AZCE6LITE[C/R][X]	THERMOSTAT [FILAIRE/RADIO] AIRZONE LITE [COULEUR]	TERMOSTATO [CAVO/RADIO] LITE [COLORE] AIRZONE	AIRZONE LITE [FARBE] THERMOSTAT [VERKABELT/FUNK]

ÍNDICE / INDEX / ÍNDICE / INDEX / INDICE / INHALT						
PAG.	ESPAÑOL [ES]	ENGLISH [EN]	PORTUGUÊS [PT]	FRANÇAIS [FR]	ITALIANO [IT]	DEUTSCH [DE]
1	ESQUEMA DETALLADO	DETAIL DIAGRAM	ESQUEMA DETALHADO	SCHÉMA DE DÉTAIL	SCHEMA DI DETTAGLIO	DETAIL-DIAGRAMM
2	ESQUEMA DE INSTALACIÓN	WIRING DIAGRAM	ESQUEMA DE INSTALAÇÃO	SCHÉMA D'INSTALLATION	SCHEMA D'INSTALLAZIONE	INSTALLATIONSVERBINDUNGS SCHEMA
3	HOJA DE REFERENCIA / LEYENDA	REFERENCE SHEET / LEGEND	FOLHA DE REFERÊNCIA / LEGENDA	FEUILLE DE RÉFÉRENCE / LÉGENDE	FOGLIO DI RIFERIMENTO / LEGENDA	REFERENZBLATT / LEGENDE