



LB035010A:



Ubicación



RS485			0-10V DAMPER			
A	-	B	+	-	+	-