






AZC25CBxMOT Connection




Installation
Manual




Power supply



Zone 1:



Zone 2:



Zone 3:

Zone 4:

Zone 5:

Zone 6:

Zone 7:

Zone 8:



LB150100C25MOT2