

AZCE8CMIVALC

AZCE8CMIVALR

AZCE8CMIDRY

AZX6AIQSNS

AZPV8CB1IAQ Connection



AZX6WSPHUB

CAN: CAN bus
AZx: Airzone
connection bus
DM1: Automation bus
IU: AC unit bus
IOx: Ionizers/Actuators
output
DI1: Alarm input
AI1: Probe input
Ox: Relais outputs

AZX6CABLEBUS


AZCE6BLUEZEROC

AZCE6LITEC

AZCE6THINKR


AZCE6LITER

1




Power supply


2




3



4



5



N Neutral
L Phase
Ground

A Blue
- Black
B Green
+ Red
Shield

Zone 1:

Zone 2:

Zone 3:

Zone 4:

Zone 5:

Zone 6:

Zone 7:

Zone 8:



LB150100E25001