






AZX6CABLEBUS



AZS62BLUEFACEC




AZS62THINKR



AZS62LITER


AZPV6CB2S62 Connection

1



Power supply

2




4

Webserver Airzone
Cloud Wi-Fi Dual 2.4-5G

5

Communication
gateway

3



N Neutral
L Phase
⏏ Ground

A Blue
- Black
B Green
+ Red

Quick Installation
Guide



Zone 1:

Zone 2:

Zone 3:

Zone 4:

Zone 5:

Zone 6:



6150100562101

